


# U-BOAT

ITALO FONTANA



# EN

## **CARE AND MAINTENANCE.**

The precision mechanism in your watch will provide long-lasting performance when properly cared for.


We recommend taking your watch to an Authorised Retailer / Authorised Service Centre every 3-4 years for a check-up and to perform ordinary maintenance on all mechanical parts.

We also advise taking your watch to an Authorised Retailer / Authorised Service Centre to change the strap.

Avoid leaving your watch where it is exposed to large temperature variations, humidity, the sun and strong magnetic fields.

## CLASSIC CHRONOGRAPH

U-77 MOVEMENT 44-HOUR POWER RESERVE



## SETTING THE TIME AND DATE.

1. Unscrew the winder protection.
2. Wind the watch if necessary.
3. Delicately pull out the winder to the first position (position A) and turn slowly to set the date.\*
4. Pull the winder out to the second position (position B) and turn slowly to set the time.
5. Press the winder back to its original position.
6. Screw the winder protection back in place.

## CHRONOGRAPH FUNCTIONS.

1. Press button C (start/stop) to start the chronograph and the hour/minute counters.
2. Press button C again to stop timing and press once more to restart.
3. After noting the time measured, press reset button D when the chronograph is stopped to return the chronograph hand and counters to zero.

\* NB: when performing this operation, make sure that the hands are not pointing to between 9 o'clock and 3 o'clock.

**U-BOAT HEAD OFFICE**

**Via per San Gennaro, 13**

**Gragnano, Capannori - 55012 Lucca - Italy**

**Tel: +39 0583 469288 - Fax: +39 0583 462249**

**[info@u-boatwatch.com](mailto:info@u-boatwatch.com)**