U-BOAT

CLASSICO

SOLOTEMPO



Dear Customer


WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE USER INSTRUCTIONS.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE U-CLUB AREA, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS, SO TO GET ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.

Mechanical Automatic

WATCH FUNCTIONS





Representative image. Some components may be in different positions or not fitted.





- POSITION 1 **NEUTRAL POSITION**
- POSITION 2 FIRST CLICK
- POSITION 3

 Unscrew the crown cover to access the crown . to wind up and start the watch, turn the crown (3) clockwise. POSITION 1 NEUTRAL POSITION pull the crown 3 out to position 2. Turn the crown 3 clockwise to set the desired date 5. Rotate the crown 3 counterclockwise **POSITION 2** FIRST CLICK to set the desired day .

2. Press the crown 3 all the way down to return it to position 1. Carefully screw down the crown cover (a) until it locks completely.

to set the desired time

POSITION 3

SECOND CLICK

pull the crown (3) out further to position 3. Rotate the crown (3)



- Your watch will keep its performance intact for a long time, with proper care.
- We recommend that you have your watch checked every 3-4 years at one of our Authorized Dealers/Authorised Service Centres, to carry out ordinary maintenance on all mechanical parts and water resistance.
- We also recommend contacting an Authorized Dealer/Authorised Service Center to replace the strap.
- Do not leave the watch in places exposed to extreme temperature changes, humidity, the sun and strong magnetic fields.
- Make sure the watch is suitable for use in water.
- Always rinse the watch with fresh water after contact with salt water.

AUTOMATIC WATCHES REQUIRE MANUAL WINDING FOLLOWING A LONG PERIOD OF INACTIVITY.

