




# STRAP SIZE GUIDE



- 1) measure the inside distance between lugs of your watch.
- 2) choose the strap that has the width corresponding to the distance between lugs.  
e.g.: U-STRAP SS **23**/22 mm

First number indicates the measure corresponding to the inside distance between lugs.  
Second number indicates the width corresponding to the inside distance between the lugs of the buckle.