

U-BOAT
ITALO FONTANA

EN

CARE AND MAINTENANCE.

The precision mechanism in your watch will provide long-lasting performance when properly cared for.

We recommend taking your watch to an Authorised Retailer / Authorised Service Centre every 3-4 years for a check-up and to perform ordinary maintenance on all mechanical parts.

We also advise taking your watch to an Authorised Retailer / Authorised Service Centre to change the strap.


Avoid leaving your watch where it is exposed to large temperature variations, humidity, the sun and strong magnetic fields.

CHRONOGRAPH FUNCTIONS.

1. Press button H (start/stop) to start the chronograph and the hour/minute counters. **2.** Press the button H again to stop the chronograph and once more to restart it. **3.** After noting the time measured, press reset button B when the chronograph is stopped to return the chronograph hand and counters to zero.

WATCH FUNCTIONS.

- A** WINDER COVER
- B** RESET
- C** DATE INDICATOR
- D** CHRONOGRAPH HOUR COUNTER
- E** CHRONOGRAPH SECOND HAND
- F** WINDER
- G** CHRONOGRAPH MINUTE COUNTER
- H** START/STOP CHRONOGRAPH
- I** SECOND COUNTER
- L** WINDER EXTRACTION BUTTON




POSITION 1
NEUTRAL POSITION



POSITION 2
FIRST CLICK



POSITION 3
SECOND CLICK



POSITION 1
NEUTRAL POSITION

To wind the watch, unscrew the winder cover **A** into the neutral position and turn the winder **F** backwards and forwards for a few seconds until the watch starts

POSITION 2
FIRST CLICK

Press the button **L** to put the winder **F** in the first position for rapid date setting.*

POSITION 3
SECOND CLICK

Press the button **L** again (second position) for precise time setting.

We advise you to turn the minute hand past the desired time and then back to the exact position.

Close the winder **F** and return the winder cover **A** to its original position; turn until it stops.

* NB: when performing this operation, make sure the watch hands are not pointing to between 9 o'clock and 3 o'clock.

U-BOAT HEAD OFFICE

Via Pesciatina, 751H

Gragnano, Capannori - 55010 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

info@u-boatwatch.com