

U-BOAT
ITALO FONTANA

EN

DEAR CLIENT,

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE INSTRUCTIONS FOR USE, THE TECHNICAL DETAILS AND THE WARRANTY BOOKLET.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH


ON OUR OFFICIAL WEB SITE

IN THE U-CLUB AREA, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS AND GAIN ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.


EN

WATCH FUNCTIONS.

- A** CROWN
- B** HOUR HAND
- C** MINUTE HAND
- D** SECOND HAND
(IF FITTED)



REPRESENTATIVE IMAGE.



POSITION 1
NEUTRAL POSITION

POSITION 2
FIRST CLICK

INSTRUCTIONS FOR USE.

POSITION 1 Watch operating position.
NEUTRAL POSITION

POSITION 2 Pull out crown **A** and turn to adjust time.
FIRST CLICK

2. Fully press crown **A** back into the neutral position.

NB: we advise pulling out crown **A** into position 2 when the watch isn't being used for a long period to limit battery consumption.

EN

CARE AND MAINTENANCE.

The precision mechanism in your watch will provide long-lasting performance when properly cared for.

We recommend taking your watch to an Authorised Retailer / Authorised Service Centre every 3-4 years for a check-up and to perform ordinary maintenance on all mechanical parts.

We also advise taking your watch to an Authorised Retailer / Authorised Service Centre to change the strap and battery.

Avoid leaving your watch where it is exposed to large temperature variations, humidity, the sun and strong magnetic fields.

Remember to rinse the watch after it comes into contact with seawater.