



U-BOAT

ITALO FONTANA

BLACK SWAN



Dear Customer

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE USER INSTRUCTIONS.


WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE **U-CLUB AREA**, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS, SO TO GET ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.

Automatic Mechanical

- A** CROWN COVER
- B** CROWN
- C** HOUR HAND
- D** MINUTE HAND
- E** SECONDS HAND
- F** DATE



Representative image.
Some components may be in different positions or not fitted.



- **POSITION 1**
NEUTRAL POSITION
- **POSITION 2**
FIRST CLICK
- **POSITION 3**
SECOND CLICK

1. Unscrew the crown cover **A** to access the crown **B**.
POSITION 1 to wind up and start the watch, turn the crown **B** clockwise.

NEUTRAL POSITION

POSITION 2 pull the crown **B** out to position 2. Turn the crown **B** clockwise to set the desired date* **F**.

FIRST CLICK

POSITION 3 pull the crown **B** out to position 3. Turn the crown **B** clockwise to set the desired time.

SECOND CLICK

2. Press the crown **B** all the way down to return it to position 1. Carefully screw down the crown cover **A** until it locks completely.

***Warning:** when carrying out this operation it is necessary to make sure that the watch hands are not positioned between 21.00 and 03:00 o'clock.

- Your watch will keep its performance intact for a long time, with proper care.
- We recommend that you have your watch checked every 3-4 years at one of our Authorized Dealers/Authorised Service Centres, to carry out ordinary maintenance on all mechanical parts and water resistance.
- We also recommend contacting an Authorized Dealer/Authorised Service Center to replace the strap.
- Do not leave the watch in places exposed to extreme temperature changes, humidity, the sun and strong magnetic fields.
- Jewel watch, avoid contact with water.

AUTOMATIC WATCHES REQUIRE MANUAL WINDING FOLLOWING A LONG PERIOD OF INACTIVITY.





U-BOAT HEAD OFFICE

Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

www.uboatwatch.com - service@u-boatwatch.com