

**U-BOAT**  
ITALO FONTANA

**CAPSOIL**  
CHRONO



*Dear Customer*

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.


IN THIS BOOKLET YOU WILL FIND THE INSTRUCTIONS FOR USE.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE **U-CLUB AREA**, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS AND GAIN ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.

Quartz




## WATCH INSTRUCTIONS

- A** START AND STOP CHRONOGRAPH
- B** RESET CHRONOGRAPH
- C** SCREW CROWN
- D** HOUR HAND
- E** MINUTE HAND
- F** CHRONOGRAPH SECOND HAND
- G** SECOND HAND
- H** CHRONOGRAPH MINUTE HAND
- I** CHRONOGRAPH HOUR HAND



Representative image.  
Some components may be in different positions or not fitted.



1. Unscrew the crown  and bring it into the position 3.
2. Turn crown  to set the desired time.
3. Screw down the crown  to put it back into position 1.

**NB:** we advise pulling out crown  into position 3 when the watch isn't being used for a long period to limit battery consumption.

## CHRONOGRAPH OPERATION INSTRUCTIONS



1. Press button **A** to start the chronograph.  
Press button **A** again to stop the chronograph.
2. Press button **B** to reset the chronograph.




1. Press button **A** to start the chrono function.
2. Press button **B** to stop the chrono function and read the intermediate time while the timing continues. By pressing button **B** again the chronograph hands recover the elapsed time.
3. 1\* Start  
2\* Time reading  
3\* Restart  
4\* Time reading  
5\* Restart  
6\* Stop

## ADJUSTING CHRONOGRAPH HANDS TO CORRECT POSITION



1. Unscrew the crown **C** and bring it into the position 3.
2. Press buttons **A** and **B** together for about 2 seconds.  
Hand **F** will rotate through 360°. (IF FITTED)  
Pressing button **A** returns hand **F** to the correct position. (IF FITTED)  
Press button **B** to activate correction of hand **I**.  
Press button **A** to return hand **I** to the correct position.  
Pressing button **B** again activates correction of hand **H**.  
Press button **A** to return hand **H** to the correct position.
3. Screw down the crown **C** to put it back into position 1.





## BATTERY REPLACEMENT AND OIL ADJUSTMENT

1. Innovative closure system with a compartment for quick battery change. **L**
2. Closing system for oil regulation in the case, exclusively by U-BOAT specialized technicians. **M**

**NB:** the oily fluid inside the case may be subject to slight changes in shade due to the natural change of the liquid.



## CARE AND MAINTENANCE

- The precision mechanism in your watch will provide long-lasting performance when properly cared for.
- We recommend taking your watch to an Authorised Retailer/Authorised Service Centre every year for a check-up, perform ordinary maintenance on all mechanical parts and restore of water-resistance.
- We also advise taking your watch to an Authorised Retailer/Authorised Service Centre to change the strap.
- Avoid leaving your watch where it is exposed to large temperature variations, humidity, the sun and strong magnetic fields.
- Make sure the watch is in adequate conditions for water use/activities.
- Remember to rinse the watch after it comes into contact with seawater.
- We suggest pulling out the crown when the watch is not being used for a long period of time in order to limit battery consumption. We advise taking your watch to an authorised Retailer/authorised Service Centre to replace the battery.

**OPTIMAL OPERATING CONDITIONS 0°/+60°C WHEN NOT WORK.**



## U-BOAT HEAD OFFICE

Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

[www.uboatwatch.com](http://www.uboatwatch.com) - [service@u-boatwatch.com](mailto:service@u-boatwatch.com)