

SPECIAL EDITIONS

FIRENZE



Dear Eustomer

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE USER INSTRUCTIONS.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE **U-CLUB AREA**, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS, SO TO GET ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.

Automatic Mechanical

WATCH FUNCTIONS

- A CROWN COVER
- CROWN
- HOUR HAND
- MINUTE HAND



Representative image. Some components may be in different positions or not fitted.





- POSITION 1
- POSITION 2
 - SECOND CLICK

1. Unscrew the crown cover (a) to access the crown (b).

POSITION 1 to wind up and start the watch, turn the crown (5) clockwise.

POSITION 2 pull the crown 3 out to position 2. Turn the crown 3 clockwise to set the desired time.

2. Press the crown 3 all the way down to return it to position 1. Carefully screw down the crown cover 3 until it locks completely.



- Your watch will keep its performance intact for a long time, with proper care.
- We recommend that you have your watch checked every 3-4 years at one of our Authorized Dealers/Authorised Service Centres, to carry out ordinary maintenance on all mechanical parts and water resistance.
- \bullet We also recommend contacting an Authorized Dealer/Authorised Service Center to replace the strap.
- Do not leave the watch in places exposed to extreme temperature changes, humidity, the sun and strong magnetic fields.
- Jewel watch, avoid contact with water.

AUTOMATIC WATCHES REQUIRE MANUAL WINDING FOLLOWING A LONG PERIOD OF INACTIVITY.



Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy Tel: +39 0583 469288 - Fax: +39 0583 462249

www.uboatwatch.com - service@u-boatwatch.com