U-BOAT



LADY

Dear Customer

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE INSTRUCTIONS FOR USE.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE U-CLUB AREA, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS AND GAIN ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.

WATCH INSTRUCTIONS



Representative image. Some components may be in different positions or not fitted.

A CROWN


B HOUR HAND

MINUTE HAND

D DATE



INSTRUCTIONS FOR USE



POSITION 1 EUTRAL POSITION	watch operating position.
POSITION 2 RST CLICK	pull out crown 🔕 and turn to adjust date.
OSITION 3	pull out crown 🔇 and turn to adjust time.

Fully press crown back into the neutral position.

NB: we advise pulling out crown a into position 2 when the watch isn't being used for a long period to limit battery consumption.





- The precision mechanism in your watch will provide long-lasting performance when properly cared for.
- We recommend taking your watch to an Authorised Retailer/Authorised Service Centre every 3-4 years for a check-up and to perform ordinary maintenance on all mechanical parts and restore of water-resistance.
- We also advise taking your watch to an Authorised Retailer/Authorised Service Centre to change the strap.
- Avoid leaving your watch where it is exposed to large temperature variations, humidity, the sun and strong magnetic fields.
- Make sure the watch is in adequate conditions for water use/activities.
- Remember to rinse the watch after it comes into contact with seawater.



U-BOAT HEAD OFFICE

Via Pesciatina 751H Gragnano, Capannori - 55010 Lucca - Italy Tel: +39 0583 469288 - Fax: +39 0583 462249

www.uboatwatch.com - service@u-boatwatch.com