

U-47



Dear Customer

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE INSTRUCTIONS FOR USE.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE **U-CLUB AREA**, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS AND GAIN ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.

WATCH INSTRUCTIONS

Automatic Mechanical



CROWN

DATE

Representative image. Some components may be in different positions or not fitted.

AUTOMATIC MECHANICAL • U-47 7

INSTRUCTIONS FOR USE





POSITION 1 NEUTRAL POSITION	unscrew the crown () to wind and start the watch.
POSITION 2 FIRST CLICK	carefully pull the crown (a) right out to the first click. Turn the crown (a) clockwise to set the date (2).
POSITION 3 SECOND CLICK	carefully pull the crown ③ right out to the second click. Turn the crown ④ to set the exact time.

2. Fully depress the crown **3** to move it back into the neutral position. Carefully screw in the cap crown **4** until firmly in place.



CARE AND MAINTENANCE

 The precision mechanism in your watch will provide long-lasting performance when properly cared for.

• We recommend taking your watch to an Authorised Retailer/Authorised Service Centre every 3-4 years for a check-up and to perform ordinary maintenance on all mechanical parts.

• We also advise taking your watch to an Authorised Retailer/Authorised Service Centre to change the strap.

 Avoid leaving your watch where it is exposed to large temperature variations, humidity, the sun and strong magnetic fields.

• Remember to rinse the watch after it comes into contact with seawater.

AUTOMATIC WATCHES REQUIRE MANUAL WINDING FOLLOWING A LONG PERIOD of inactivity.

U-BOAT HEAD OFFICE

Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy Tel: +39 0583 469288 - Fax: +39 0583 462249

www.uboatwatch.com - service@u-boatwatch.com