

**U-BOAT**  
ITALO FONTANA

CLASSICO

SOLOTEMPO



*Dear Customer*

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE INSTRUCTIONS FOR USE.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE **U-CLUB AREA**, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS AND GAIN ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.


# Mechanical Automatic

## WATCH INSTRUCTIONS

- A CAP CROWN
- B CROWN
- C HOUR HAND
- D MINUTE HAND
- E SECOND HAND
- F DATE
- G DAY



Representative image.  
Some components may be in different positions or not fitted.



- **POSITION 1**  
NEUTRAL POSITION
- **POSITION 2**  
FIRST CLICK
- **POSITION 3**  
SECOND CLICK

1. Unscrew the cap crown **A** to gain access to the crown **B**.

**POSITION 1**  
NEUTRAL POSITION

to recharge and start the watch, turn the crown **B** clockwise.

**POSITION 2**  
FIRST CLICK

pull out the crown **B** and rotate it clockwise to set the date **F**, rotate the crown **B** counterclockwise to set the day **G**.

**POSITION 3**  
SECOND CLICK

Pull out the crown **B** further and rotate it to set the exact time.

2. Push the crown **B** fully to return it to the neutral position. Carefully screw in the cap crown **A** until it is completely locked.



## CARE AND MAINTENANCE

- The precision mechanism in your watch will provide long-lasting performance when properly cared for.
- We recommend taking your watch to an Authorised Retailer/Authorised Service Centre every 3-4 years for a check-up and to perform ordinary maintenance on all mechanical parts and restore of water-resistance.
- We also advise taking your watch to an Authorised Retailer/Authorised Service Centre to change the strap.
- Avoid leaving your watch where it is exposed to large temperature variations, humidity, the sun and strong magnetic fields.
- Make sure the watch is in adequate conditions for water use/activities.
- Remember to rinse the watch after it comes into contact with seawater.

**AUTOMATIC WATCHES REQUIRE MANUAL WINDING FOLLOWING A LONG PERIOD OF INACTIVITY.**



## U-BOAT HEAD OFFICE

Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

[www.uboatwatch.com](http://www.uboatwatch.com) - [service@u-boatwatch.com](mailto:service@u-boatwatch.com)