

An aerial, black and white photograph of Rome, Italy. The Colosseum is the central focus, but it is depicted as a large, circular submarine (U-Boat). The structure of the Colosseum forms the hull of the submarine, with its arches and tiers visible. The interior of the Colosseum is filled with water, and the word "AUTOMATIC" is written on the inner rim. The surrounding city of Rome, with its dense collection of buildings and streets, is visible in the background, suggesting the submarine is hidden beneath the city.

U-BOAT

ITALO FONTANA

SPECIAL EDITIONS

ROMA



Dear Customer

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE USER INSTRUCTIONS.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE **U-CLUB AREA**, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS, SO TO GET ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.

Automatic Mechanical

- A CROWN
- B HOUR HAND
- C MINUTE HAND
- D SECONDS HAND

WATCH FUNCTIONS



Representative image.
Some components may be in different positions or not fitted.



- **POSITION 1**
NEUTRAL POSITION
- **POSITION 2**
SECOND CLICK

USER INSTRUCTIONS

POSITION 1 to wind up and start the watch, turn the crown **A** clockwise.

NEUTRAL POSITION

POSITION 2 pull the crown **A** out to position 2. Turn the crown **A** clockwise to set the desired time.

SECOND CLICK

Press the crown **A** all the way down to return it to position 1.



CARE AND MAINTENANCE

- Your watch will keep its performance intact for a long time, with proper care.
- We recommend that you have your watch checked every 3-4 years at one of our Authorized Dealers/Authorised Service Centres, to carry out ordinary maintenance on all mechanical parts and water resistance.
- We also recommend contacting an Authorized Dealer/Authorised Service Center to replace the strap.
- Do not leave the watch in places exposed to extreme temperature changes, humidity, the sun and strong magnetic fields.
- Jewel watch, avoid contact with water.

AUTOMATIC WATCHES REQUIRE MANUAL WINDING FOLLOWING A LONG PERIOD OF INACTIVITY.



U-BOAT HEAD OFFICE

Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

www.uboatwatch.com - service@u-boatwatch.com