U-BOAT

DIVE WATCH

SOMMERS0



Dear Customer

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE USER INSTRUCTIONS.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE U-CLUB AREA, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS, SO TO GET ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.


Mechanical Automatic

WATCH FUNCTIONS

A CROWN COVER
B SCREW CROWN
HOUR HAND
MINUTE HAND
SECONDS HAND
24 HOURS INDICATOR
DATE
UNIDIRECTIONAL BEZEL



Representative image. Some components may be in different positions or not fitted.



. Unscrew the c	rown cover 🙆 to access the crown 😉.
POSITION 1 EUTRAL POSITION	to wind up and start the watch, unscrew the crown 3 and turn it clockwise.
POSITION 2 RST CLICK	pull the crown 3 out to position 2. Turn the crown 3 clockwise to set the desired date 3.
POSITION 3 ECOND CLICK	pull the crown ① out further to position 3. Rotate the crown ② to set the desired time. Consider the indicator ③ (24 hours) for the correct click of the date ②.

- 2. Press the crown 3 all the way down, screwing it carefully to bring it back to position 1. Screw the crown cover 2 carefully until it locks completely.
- **3.** The bezel (1) rotates counterclockwise.



- Your watch will keep its performance intact for a long time, with proper care.
- We recommend that you have your watch checked every 3-4 years at one of our Authorized Dealers/Authorised Service Centres, to carry out ordinary maintenance on all mechanical parts and water resistance.
- We also recommend contacting an Authorized Dealer/Authorised Service Center to replace the strap.
- Do not leave the watch in places exposed to extreme temperature changes, humidity, the sun and strong magnetic fields.
- Always rinse the watch with fresh water after contact with salt water.

AUTOMATIC WATCHES REQUIRE MANUAL WINDING FOLLOWING A LONG PERIOD OF INACTIVITY.

ABSOLUTELY DIVE WATCH

ASSOLUTAMENTE SOMMERSO



