U-BOAT





Dear Customer

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.

IN THIS BOOKLET YOU WILL FIND THE USER INSTRUCTIONS.

WE KINDLY INVITE YOU TO REGISTER YOUR WATCH ON OUR OFFICIAL WEB SITE IN THE **U-CLUB AREA**, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES OWNERS, SO TO GET ACCESS TO FURTHER BENEFITS AND PREVIEWS ON OUR LATEST NEWS, EVENTS AND OFFERS.

WATCH FUNCTIONS



A	CROWN
B	BEZEL CROWN
0	DUAL TIME BEZEL
D	HOUR HAND
D	DUAL TIME HAND
8	MINUTE HAND



Representative image. Some components may be in different positions or not fitted.

QUARTZ • CAPSOIL DOPPIOTEMPO |7

USER INSTRUCTIONS





POSITION 1

NEUTRAL POSITION

POSITION 2

FIRST CLICK

POSITION 1 operating position of the watch.

POSITION 2 unscrew crown **a** and pull it out to take it to position 2. Rotate the crown **a** to set the desired time.

Push in and screw the crown (A) back to position 1.

Note: it is recommended to unscrew the crown \bigcirc to position 2 when the watch will not be used for a long time, to limit battery consumption.

1. Unscrew the crown ^(B).

2. Rotate the bezel \bigcirc to set the second time. (Refer to the hand \bigcirc).

3. Press in and screw the crown (B) back in to return to the neutral position.





BATTERY REPLACEMENT AND OIL ADJUSTMENT

Innovative closure system with a compartment for quick battery change **()**.
Closing system and internal oil regulation, for the exclusive use of U-BOAT specialized technicians ().

Note: the oily fluid inside the case may be subject to slight changes in shade due to the natural change of the liquid.

12 CAPSOIL DOPPIOTEMPO • QUARTZ



CARE AND MAINTENANCE

• Your watch will keep its performance intact for a long time, with proper care.

 We recommend that you have your watch checked every 3-4 years at one of our Authorized Dealers/Authorised Service Centres, to carry out ordinary maintenance on all mechanical parts and water resistance.

• We also recommend contacting an Authorized Dealer/Authorised Service Center to replace the strap.

 Do not leave the watch in places exposed to extreme temperature changes, humidity, the sun and strong magnetic fields.

• Make sure the watch is suitable for use in water.

• Always rinse the watch with fresh water after contact with salt water.

 It is advisable to unscrew the crown when the watch will not be used for a long time, to limit battery consumption. We recommend that you contact an authorized center to replace the battery.

OPTIMAL OPERATING CONDITIONS: 0°/+60°C.

QUARTZ • CAPSOIL DOPPIOTEMPO |15

INNOVATION AND STYLE

STILE ED INNOVAZIONE



U-BOAT HEAD OFFICE

Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy Tel: +39 0583 469288 - Fax: +39 0583 462249

www.uboatwatch.com - service@u-boatwatch.com