

**U-BOAT**  
ITALO FONTANA

CLASSICO

U-46



*Dear Client*

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT MODEL.

IN THIS MANUAL YOU WILL FIND THE INSTRUCTIONS FOR YOUR WATCH.

WE THANK YOU FOR YOUR TRUST AND INVITE YOU TO REGISTER ON OUR OFFICIAL WEBSITE IN THE **U-CLUB** SECTION DEDICATED EXCLUSIVELY TO OWNERS/POSSITORS OF U-BOAT PRODUCTS, IN ORDER TO RECEIVE ADDITIONAL ADVANTAGES, AND BE INFORMED ABOUT OFFERS, EVENTS AND NEWS IN PREVIEW.



# Mechanic Automatic

## WATCH FUNCTIONS

- A CUP CROWN
- B CROWN
- C HOURS HAND
- D MINUTES HAND
- E SECONDS HAND
- F 24 HOUR INDICATOR
- G DATE



Indicative image  
Some components may be missing  
or arranged in a different position.



- **POSITION 1**  
NEUTRAL POSITION
- **POSITION 2**  
FIRST CLICK
- **POSITION 3**  
SECOND CLICK

1. Unscrew the cup crown **A** to access the crown **B**.

**POSITION 1** to charge and start the watch, turn the crown **B** clockwise  
NEUTRAL POSITION

**POSITION 2** Extract the crown **B**. To bring it in position 2.  
FIRST CLICK turn the crown **C** clockwise to set the date **G**

**POSITION 3** Extract again the crown **B**, to bring it in position 3.  
SECOND CLICK Turn the crown **C** Clockwise to set to the desired time.

2. Push the crown **C** Back in to position 1. To screw the cup crown **A** until it is completely blocked .



## CARE AND MAINTENANCE

- Your watch will maintain its performance intact for a long time, with the appropriate care.
- We recommend that you have your watch checked every 3-4 years by one of our Authorized Retailers/Authorized Service Centers, to carry out normal maintenance of all mechanical parts and water resistance.
- We also recommend that you contact an Authorized Retailer/Authorized Service Center to replace the strap.
- Avoid leaving your watch in places exposed to strong temperature variations, humidity, sunlight and intense magnetic fields.
- Make sure that your watch is suitable for use in water.
- Always rinse your watch with fresh water after contact with salt water.
- Automatic watches require manual winding after a long period of inactivity.

**AUTOMATIC WATCHES REQUIRE MANUAL WINDING AFTER A LONG PERIOD OF INACTIVITY**



## U-BOAT HEAD OFFICE

Via Pesciatina 751H

Gradano, Capannori - 55010 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

[www.uboatwatch.com](http://www.uboatwatch.com) - [service@u-boatwatch.com](mailto:service@u-boatwatch.com)