

**U-BOAT**  
ITALO FONTANA

U - 65 AUTOMATIC

---



*Dear Customer*

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT MODEL.


IN THIS MANUAL YOU WILL FIND THE INSTRUCTIONS FOR YOUR WATCH.

WE THANK YOU FOR YOUR TRUST AND INVITE YOU TO REGISTER ON OUR OFFICIAL WEBSITE IN THE [U-CLUB](#) SECTION DEDICATED EXCLUSIVELY TO OWNERS/POSSITORS OF U-BOAT PRODUCTS, IN ORDER TO RECEIVE ADDITIONAL ADVANTAGES, AND BE INFORMED ABOUT OFFERS, EVENTS AND NEWS IN PREVIEW.


# Mechanic Automatic

## WATCH FUNCTIONS

- A CROWN
- B HOURS HAND
- C MINUTES HAND
- D SECONDS HAND



Indicative image  
Some components may be missing  
or arranged in a different position.



• **POSITION 1**  
**NEUTRAL POSITION**

Position of the crown in neutral phase. **A**

• **POSITION 2**  
**FIRST CLICK**

Pull out crown **A** to bring it to position 2.  
Rotate crown **A** to set the desired time.

Press the crown **A** back into position 1.



## CARE AND MAINTENANCE

- Your watch will maintain its performance intact for a long time, with the appropriate care.
- We recommend that you have your watch checked every 3-4 years by one of our Authorized Retailers/Authorized Service Centers, to carry out normal maintenance of all mechanical parts and water resistance.
- We also recommend that you contact an Authorized Retailer/Authorized Service Center to replace the strap.
- Avoid leaving your watch in places exposed to strong temperature variations, humidity, sunlight and intense magnetic fields.
- Make sure that your watch is suitable for use in water.
- Always rinse your watch with fresh water after contact with salt water.
- Automatic watches require manual winding after a long period of inactivity.



**U-BOAT HEAD OFFICE**

Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

[www.uboatwatch.com](http://www.uboatwatch.com) - [service@u-boatwatch.com](mailto:service@u-boatwatch.com)